

POD STOOLINSTRUCTIONS FOR ADJUSTMENT

www.workspace.com.au Sydney | Melbourne | Adelaide | Canberra | Brisbane



① **SEAT HEIGHT:** Pull up on the paddle lever and allow the gasspring to lift the seat. Release the lever when the desired height is reached.