

TOUCH CHAIR

INSTRUCTIONS FOR ADJUSTMENT



- ① **SEAT HEIGHT:** Pull up on the paddle lever and allow the gas-spring to lift the seat. Release the lever when the desired height is reached.
- ② **BACK TILT LOCK:** There are five tilt positions. As the knob is rotated anti-clockwise the tilt angle increases until the fifth position is reached.
- ③ **ARMREST HEIGHT ADJUSTMENT:** Press the button on the outer side of either arm-rest to unlock. Then slide arm-rest up or down to the desired height and release button.
- ④ **ARMREST POSITION ADJUSTMENT:** The armrests can be individually slid forward or back and rotated from side-to-side to a desired position.
- ⑤ **LUMBAR SUPPORT:** The rear of the chair has a handle that can be pulled out or pushed in to adjust the lumbar support.