

RESPONSE CHAIR

INSTRUCTIONS FOR ADJUSTMENT



- ① **SEAT HEIGHT:** Pull up on the paddle lever and allow the gas-spring to lift the seat. Release the lever when the desired height is reached.
- ② **BACK TILT LOCK:** With the lever in the down position, push the backrest to the desired tilt position and then pull the lever up to lock. To release simply push the lever down.
- ③ **SEAT DEPTH:** Pull the handle up and slide the seat forward or backward. Release the handle when the seat is at the desired position.
- ④ **SEAT TILT SPRING TENSION:** Rotate the knob clockwise or anti-clockwise to increase or decrease tilt resistance.
- ⑤ **ARMREST WIDTH:** By turning the knobs under the armrests they can be loosened. Once loose slide in or out to desired position and then re-tighten knobs.
- ⑥ **ARMREST HEIGHT ADJUSTMENT:** Press the button on the outer side of either arm-rest to unlock. Then slide arm-rest up or down to the desired height and release button.
- ⑦ **ARMREST POSITION ADJUSTMENT:** The armrests can be individually slid forward or back and rotated from side-to-side to a desired position. Additionally, there is a button on the inner side of the armrests that allows extended adjustment.