

ECLIPSE CHAIR

INSTRUCTIONS FOR ADJUSTMENT



1 - SEAT HEIGHT

Pull up on the paddle lever with fingertips and allow the gas spring to lift the seat. Release the lever when the desired height is reached. Your thighs should be horizontal when your feet are flat on the floor.

2 - BACK TILT ANGLE

Tilt can be unlocked (for free movement) or locked into any position. Push down on lever to lock back tilt to nearest position while leaning back to required angle. There are 5 positions to choose from. Pull lever up to unlock for free movement. For safety, the back will not unlock until you lean against it.

3 - BACK TILT TENSION

Rotate the knob under the seat clockwise to increase the tilt tension (this is the resistance felt when leaning back) Rotate anti-clockwise to reduce tension.

4 - BACK LUMBAR SUPPORT

Slide the lumbar support pad at the back of the chair up or down to required position. Rotate the knob to move the lumbar support pad forward or back.

5 - ARM WIDTH (ADJUSTABLE ARMS)

Arms can be moved sideways by undoing the knob found under the seat at each arm bracket.

6- ARM HEIGHT (ADJUSTABLE ARMS)

Press the button in at the side of the arm to lift to one of 7 positions. Arm pads can also be rotated to the left or right.

workspace
commercial furniture

SYDNEY - MELBOURNE - ADELAIDE - CANBERRA - BRISBANE

www.workspace.com.au